



Notes:

/ Secure the pre-formed aluminium corner moulding to corner stud prior to installing Nuline™ Plus weatherboards.

/ Install Nuline™ Plus weatherboard snug into aluminium corner, ensure bottom edge is covered by the moulding.

/ Tongue and groove ends will need to be removed to ensure complete cover at external and internal corners.

*Components not supplied by BGC